



SABRE BLADES

INSTALLATION MANUAL

1. **Prepare and clean your deck**
Remove griptape, clean deck surface with a solvent (cleaning alcohol)
2. **Attach Sabre Blades to the deck**
3M VHB Tape: Remove film from VHB tape, align protruding blade edge with the deck, press pad firmly onto the deck. Push down working your way around the edges of the pad.
Epoxy: When using epoxy, clamp the pads down during curing time in order to form them to the natural curve of the deck. Ensure the transitions from the pad to the deck are smooth.
3. **Apply griptape over the pads and deck**
4. **Go out and ride**

Share your results with us on Instagram @sabre_dynamics

